

Part #'s **Secret Weapon: 302-129**

Application : **2003-04 Mazdaspeed Protégé Turbo**

Parts List : 1 x Weapon*R Intake pipe. 1 x "U" shaped BOV pipe / 1 x Weapon*R Air Filter 3" / 1 x 10mm x 12" Hose
1 x 15mm hose/2 x 3" Coupler /1 x 2.5-2.5" Coupler /1 x Intake System Bracket kit /6 x 3" Clamp, 1x AIT grommet

- 1 Remove bolts securing OEM air cleaner box, loosen clamps on OEM rubber intake pipe.
- 2 Remove PCV hose from OEM intake and engine.
- 3 Disconnect the MAF sensor harness, carefully remove MAF sensor from OEM airbox,
- 4 Remove AIT grommet from OEM airbox and set aside for later instalation.
- 5 Remove the OEM rubber intake tube, remove the OEM air cleaner box by pulling upwards.
- 6 Wipe the turbo clean of any grease, install the 2.5"-2.5" coupler onto turbo, secure with OEM clamp.
- 7 Insert Weapon*R intake pipe into the 2.5"-2.5" coupler, secure with clamp.
- 8 Install the 3" coupler onto end of intake pipe, secure with clamp.
- 9 Install the MAF sensor into the 3" coupler, secure with clamp.
- 10 Install "U" shaped blow off valve adpater to 15mm port on tube using small piece of 15mm silicone.
- 11 Measure the OEM PVC hose, replace with supplied 10mm hose, install from PVC port to intake pipe.
- 12 Install AIT grommet into WR tube and reinstall AIT sensor into grommet

Note: Secret Weapon Filter Option

- 13 Install the 3" coupler onto intake pipe, secure with supplied clamp.
- 14 Install Secret Weapon filter assembly onto the end of the 3"-3" silicone secure with clamp.
- 15 Install U-shaped part of intake system bracket under the clamp on air filter.
- 16 Install the rubber mounting grommet to the closest hole to the Weapon*R air filter.
- 17 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
- 18 Secure with washer and nut included in bracket kit.
- 19 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
- 20 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
- 21 Place Weapon*R CARB Sticker on a visible place in engine compartment. (If Applicable)

WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.

Note: Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**
Report any defective or missing parts to the authorized Weapon*R dealer you purchased this product from.
Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.



* Intake kit with BOV pipe attached as shown *

Engine damper kit also available for this vehicle , for more info check our website.

If you have any Question about this Product, Please refer to our website @ WWW.WEAPON-R.COM